

MAINTENANCE GUIDELINES FOR HOMOGENEOUS RESILIENT TILE

DAILY MAINTENANCE:

- Sweep or dust mop the floor to remove any large debris.
- Damp mop or automatic scrub using a properly diluted solution of neutral pH cleaner (such as Shaw Hard Surface Cleaner) and a 3M RED pad (Use a water based treatment only).

RESTORATIVE MAINTENANCE:

- Sweep or dust mop the floor to remove any large debris.
- Damp mop or automatic scrub using a properly diluted solution of Deep Clean and a 3m RED pad. Buff if desired using a WHITE low speed polishing pad.
- Surface Treatment can also be recoated to rejuvenate as necessary. To do so, damp mop or automatic scrub using a properly diluted solution of neutral pH cleaner (such as Shaw Hard Surface Cleaner) and a 3m RED pad. Rinse with clear water, and allow to dry.
- Floor surface must be clean, dry and free of residue before Surface Treatment is applied again. Apply 1 – 2 coats following directions provided in the Homogenous Resilient Tile document.

transforming performance.